



DESIGN GUIDE



# FOOT TRAFFIC GUIDE

This Foot Traffic Guide indicates the performance of various **Stramit**® roofing profiles under differing foot traffic load conditions and should be taken into account when specifications are prepared.



#### Important note

The information contained within this brochure is as far as possible accurate at the date of publication, however, before application in a particular situation, Stramit Building Products recommends that you obtain qualified expert advice confirming the suitability of product(s) and information in question for the application proposed. While Stramit accepts its legal obligations, be aware however that to the extent permitted by law, Stramit disclaims all liability (including liability for negligence) for all loss and damage resulting from the use of the information provided in this brochure.

## Designing for foot traffic

All roofs are subject to some foot traffic during their installed life. This may be by fixers during installation or at times of routine maintenance of the roof or other equipment located on or through the roof.

**IMPORTANT.** Roofing profiles must not be considered as a walkway.

#### **Definitions**

#### **High Maintenance Traffic**

Designed to take a 1.8 kN concentrated load anywhere on the roof in accordance with AS1170 Part 1-2002 The S.A.A. Loading Code.

#### **Normal Foot Traffic**

Traditional loads generally in accordance with ASI562-1980 Design and Installation of Metal Roofing.

#### **Controlled Foot Traffic**

Loads in accordance with AS1562.1-1992 Design and Installation of Metal Sheet Roofing and Wall Cladding.

All spans given in this guide comply with both strength and serviceability (limit state) requirements.

# Foot traffic testing

In accordance with ASI 562, testing carried out for foot traffic loadings can be limited to specific areas of the roof sheet. Stramit always establishes and tests the worst case along the designated path.

# Walking on metal roofs


The designated walking area for Stramit roof products are:

#### **Flat Tray Profiles**

Walk in the trays only, whether they be concealed or through fixed. **Walk in the pan only.** 




#### WALK ONLY IN PANS



### **Multi-Ribbed Profiles**

(Stramit® Corrugated sheeting and Stramit Longspan® sheeting), distribute the load over two ribs.



#### **Product installation**

All Stramit profiles must be fixed in accordance with the procedures given in the specific product literature.

**Stramit Longspan®** sheeting and **Stramit® Corrugated** sheeting performance figures given in this brochure refer to product fixed using 3 fasteners/sheet/batten.

#### Wind loads

Spans given in this brochure apply only to foot traffic limitations. Roof and wall claddings should also be designed for wind load performance using the relevant Stramit product technical manual.

However, as a guide, and subject to individual project needs, product spans given in this foot traffic guide may be suitable for the wind load conditions as shown.

- \* Wind Load recommendations are based on applications which have:
- at least 3 spans
- maximum height of 7m
- enclosed building no more than 1,000m<sup>2</sup> in area and not affected by local topography

### **Adverse conditions**

If it is intended to use **Stramit**® roofing, walling or rainwater products within 1km of breaking surf or calm marine or in industrial, farming and unusually corrosive environments, please contact your local Stramit office for advice.

# **Roof safety**

Roof Safety is always of prime importance to installers, owners and maintenance staff. Always follow the regulations and other appropriate safety procedures and use the correct safety equipment.

When on a roof, use these hints for best results:

- Always walk in the pans of the wide tray roof sheeting, as close as possible to the roofing supports.
- Walk up the roof in pans and across the roof at supports.

- Use footwear with soft, light coloured soles that will not pick up small stones or steel filings, etc.
- Do not walk in the last pan on the edge of the roof, either while laying the sheeting or around holes for penetrations or skylights.
- With close rib sheeting, e.g. Stramit® Corrugated sheeting or Stramit Longspan® sheeting, always stand over two ribs with feet flat, and as close as possible to the sheeting supports – WALK ON SCREW LINES.
- Surfaces of ZINCALUME® and COLORBOND® are
  prone to scuffing if footwear or heavy equipment
  are dragged across the surface. This can affect
  both appearance and performance and must be
  avoided at all times. If heavy roof traffic cannot
  be avoided on certain roof areas, it is important
  to protect the sheeting by installing either
  temporary or permanent walkways.
- Distribute bodyweight evenly over the soles of the feet, trying not to concentrate weight on heel or toe.
- Do not walk on cantilever sections of the roof sheeting, e.g. overhangs into box gutters or unsupported ends around penetrations or skylights.
   These sections of the roof sheeting are not designed to take foot traffic.
- Avoid walking at the mid span of the sheeting and walk using smaller, rather than larger, steps to reduce the 'push off' spring load.
- Provide temporary protection to the roof sheeting during construction if the roof is going to be subjected to abnormal foot traffic.
- Temporary walkways can be provided during construction either by using small sandbags, or carpet covered timber blocking (on the tray) at the roof supports, to carry planking.
- When installing ZINCALUME® or light coloured COLORBOND® sheeting, wear approved sunglasses and use I5+ UV skin block out even during cloudy weather.

#### ROOFING FOOT TRAFFIC GUIDE (all spans are in mm) sheeting/decking **BMT** Int. End High **High Maintenance Traffic** Span Span Stramit Speed Deck Ultra® 0.42 1100 700 Where it is known that a roof will spans suitable for Region A & B Suburban Wind Load Applications\* ( \* except these values) 900 0.48 1400 be subjected to repeated foot traffic Stramit Speed Deck® 500 0.42 NA NA by maintenance people unaware of 0.48 NA NA the correct procedures for walking 0.60 1100 700 on metal roofs, the use of this table Stramit® Corrugated 0.42 NA NA in roof design will help prevent 0.48 750 500 Stramit® Corrugated Curving Quality future damage. 0.60 NΑ NA The recommended spans allow for Stramit Monoclad® NA 0.42 NA a loading of 1.8kN to be applied 1000 800 0.48 Stramit Megaclad® 0.42 NA NA to any part of the roof surface 0.48 800 600 (including ribs). An alternative is to Stramit Longspan® 0.42 NA NA incorporate a protective walkway Exposed 0.48 800 600 over the surface areas. Stramit CapacityPLUS™ 0.42 1200 900 NA – Shows this product is not 0.48 1500 1200 alum 0.7 NA NA applicable to this load condition. alum 0.9 NA NA sheeting/decking **BMT** Int. End **Normal Normal Foot Traffic** Span Span spans suitable for Region A & B Suburban Wind Load Applications\* ( † except these values) Stramit Speed Deck Ultra® 1700 0.42 2100 These recommendations cover 0.48 2700 2300 roofs where there will be moderate Stramit Speed Deck® 500 0.42 1500 1100 foot traffic from time to time, 0.48 2100 1700 possibly involving minor maintenance 2200<sup>†</sup> 0.60 2700<sup>†</sup> 900 Stramit® Corrugated 0.42 1200 0.48 1600 1200 Spans allow for foot traffic using Stramit® Corrugated Curving Quality 0.60 1200 900 designated walking areas with a typical load of I.IkN, and also take Stramit Monoclad® 0.42 1700 1350 account of practical installation 0.48 2300 1700 factors. Stramit Megaclad® 0.42 1500 1250 0.48 1800 1500 These spans are closely Stramit Longspan® 0.42 2100 1750 **These** Sheltered aligned with traditional span 2700 0.48 2250 limitations which have been Stramit CapacityPLUS™ 0.42 3000 3000<sup>†</sup> 0.48 3000<sup>†</sup> 3000<sup>†</sup> in use throughout Australia alum 0.7 1800 1800 for many years. 1800 1800 alum 0.9 **BMT** End sheeting/decking Int. **Controlled Foot Traffic** Controlled Span Span 0.42 2700 2250 Stramit These spans are for roofs which Speed Deck Ultra® 3600 2700 0.48 will encounter foot traffic only by Stramit 0.42 2400 2100 Wind Load Applications these spans must be checked experienced personnel. # Speed Deck® 500 0.48 3000 2400 2700 0.60 3600 The spans given comply with the Stramit® Corrugated 1500 900 0.42 foot traffic requirements of ASI562 1500 0.48 1800 - 1992 for a 0.9kN serviceability Stramit® Corrugated Curving Quality 0.60 1900 1600 load but extreme care should be exercised when roofs are installed 2100 1800 Stramit Monoclad® 0.42 based on these conditions to 0.48 2700 2250 prevent any unsightly aesthetic Stramit Megaclad® 0.42 1800 1500 imperfections. 0.48 2100 1800 Stramit Longspan® 0.42 2400 1800 Ö If these recommendations are 0.48 3000 2250 incorporated into the roofing Stramit CapacityPLUS 0.42 3000 3000 design, the designated walking 0.48 3000 3000 1800 1800 alum 0.7 areas must be used. alum 0.9 1800 1800

<sup>#</sup>WARNING – All snap together decks (with the exception of **Stramit Speed Deck Ultra**® decking) may require special installation procedures when spans exceed the normal foot traffic limitations.



# The Stramit web page can be found at:

#### www.stramit.com.au

Details of many **Stramit**\* products can also be seen on the AIA site 'Product Selector' at: www.selector.com.au

<b>Building Products</b>		prices	availability	general	technical		
contact numbers for information			products coating colours	other	advice product data		
SYDNEY 33-83 Quarry Road, Erskine Park NSW 2759	phone fax	(02) 9834 0909 (02) 9834 0988		(02) 9834 0900 (02) 9834 0988			
CANBERRA 4 Bass Street, Queanbeyan NSW 2620	phone fax	<b>(02) 6297 3533</b> (02) 6297 8089					
COFFS HARBOUR 6 Mansbridge Drive, Coffs Harbour NSW 2450	phone fax		(02) 6652 6333 (02) 6651 3395		<b>(02) 4954 5033</b> (02) 4954 5856		
NEWCASTLE 17 Nelson Road, Cardiff NSW 2285	phone fax	<b>(02) 4954 5033</b> (02) 4954 5856					
ORANGE 51 Leewood Drive, Orange NSW 2800	phone fax		<b>(02) 6361 0444</b> (02) 6361 9814				
MELBOURNE 2/1464 Ferntree Gully Road, Knoxfield VIC 3180	phone fax	<b>(03) 9237 6300</b> (03) 9237 6399		(03) 9237 6200 (03) 9237 6299			
ALBURY 18 Ariel Drive, Albury NSW 2640	phone fax		<b>(02) 6041 7600</b> (02) 6041 7666				
<b>BENDIGO</b> Ramsay Court, Kangaroo Flat VIC 3555	phone fax		<b>(03) 5447 8455</b> (03) 5447 9677				
HOBART 57 Crooked Billett Drive, Brighton TAS 7030	phone fax		<b>(03) 6263 5536</b> (03) 6263 6950		(03) 6263 5536		
<b>LAUNCESTON</b> 289 Hobart Road, Kings Meadows TAS 7249	phone fax		( <b>03) 6343 7390</b> ( <b>03</b> ) 6343 7381		(03) 6263 6950		
ADELAIDE II Stock Road, Cavan SA 5094	phone fax		(08) 8262 4444 (08) 8262 6333		(08) 8262 4444 (08) 8262 6333		
BRISBANE 57-71 Platinum Street, Crestmead QLD 4132	phone fax		(07) 3803 9999 (07) 3803 1499				
<b>TOWNSVILLE</b> 402-408 Bayswater Road, Garbutt QLD 4814	phone fax	(07) 4779 0844 (07) 4775 7155 (07) 4045 3069 (07) 4045 4762 (07) 4942 3488 (07) 4942 2343 (07) 4121 2433 (07) 4123 3139			(07) 3803 9999 (07) 3803 1499		
CAIRNS Vickers Street, Edmonton QLD 4869	phone fax						
MACKAY Brickworks Court, Glenella QLD 4740	phone fax						
MARYBOROUGH 10 Activity St, Maryborough QLD 4650	phone fax						
ROCKHAMPTON 41 Johnson St, Parkhurst QLD 4702	phone fax		<b>(07) 4936 2577</b> (07) 4936 4603				
SUNSHINE COAST Unit 1, 5 Kerryl St, Kunda Park QLD 4556	phone fax		(07) 5456 4083 (07) 5456 4862				
MURWILLUMBAH 6 Kay Street, Murwillumbah NSW 2484	phone fax	(02) 6672 8542 (02) 6672 6798					
<b>DARWIN</b> 55 Albatross Street, Winnellie NT 0820	phone fax		(08) 8947 0780 (08) 8947 1577				
PERTH 605-615 Bickley Road, Maddington WA 6109	phone fax		` ,	<b>93 8800</b> 93 8899			
<b>BUNBURY</b> 25 Proffit Street, Bunbury WA 6230	phone fax		` ,	<b>21 8046</b> 21 8017			

® Registered trademarks of Stramit Corporation Pty Limited. ABN 57 005 010 195 trading as Stramit Building Products

A member of the Fletcher Building Group

COLORROND® and ZINCALLIME® are registered trademarks of BlueScope Steel Limited

COLORBOND® and ZINCALUME® are registered trademarks of BlueScope Steel Limited © Stramit Corporation Pty. Limited August 2009.